

Angled Stairs Assembly Instructions



Step 1. Assemble sub frame. Will consist of two post legs, three side stretches, one to go across the lower legs, one front rail and one back rail.



Step 2. Lay out the twelve (12) platform rails and space them evenly apart. Screw them on to the sub frame. Use the 2-1/2" Drywall Screws we provided for the entire installation.



Step 3. Assemble the two (2) ladder legs and the stair stretchers.





Step 4. Place the remaining six (6) steps onto the stretchers and screw them in.

Step 5. Attach the ladder legs to the sub frame. It may be easier to attach the steps on the ladder legs prior to attaching it to the frame.

Parts List:

70- 2-1/2" Drywall Screws

6-2" x 2" x 7" Wood

12-2" x 4" x 22" Wood

8-2" x 4" x 20-1/2" Wood

2-2" x 6" x 47" Wood

2-2" x 4" x 34" Wood

2-2" x 4" x 37-1/2" Wood

1-2" x 4" x 40-1/2"